

TITAN



Spare Parts List

TITAN Strapping Systems

HR32

Manual Pusher Tensioner for Steel Strapping

3 / 4 – 1 - 1 / 4



TITAN Strapping Systems


306 West Plaza Drive, Suite B15 • Mooresville, NC 28117

Phone: (704) 663-2490 • Fax: (704) 663-2489

[Email: rep@titanstrapping.com](mailto:rep@titanstrapping.com)

Pos.	Description	Item Number
1	Circular chuck cone	4427100110
2	Buckling guide rail	4452100310
3	Leg spring	3452100400
4	Cylinder pin	1112060406
5	Threaded pin	1085080080
6	Sliding plate Countersunk head screw	4452100500
7	Hex.nut	1005060114
8	Hex. Screw	1408060012
9	Stopper plate Countersunk head screw	1013060170
10	Leg spring	4427101000
11	Bearing plate	1005060132
12	Needle sleeve	3427101200
14	Needle bushing	4427101400
15	Needle sleeve	1520012124
16	Needle sleeve	1530012129
17	Needle sleeve	1520016124
18	Drill socket	1711212000
20	Tension wheel	4452101520
21	Set collar	4427102100
22	Threaded pin	1086030050
23	Toothed wheel shaft	4427102300
24	Locking washer	1361000900
25	Pinion shaft	4427102500

Pos.	Description	Item Number
26	Gear cover	4427102600
27	Starting disc	4427102700
28	Fork head	4427102810
29	Tube for ratchet lever	4427102900
30	Tension handle	4427103000
31	Rod for release	4427103100
32	Tension sleeve	1141040109
33	Locking ring	1242170000
34	Washer	1302084010
35	Pressure spring	3427103500
36	Pusher	4427103600
37	Headless screw	4427110000
38	Bearing ring	3427103800
39	Ratchet	4427103900
40	Washer	4427104000
41	Countersunk head screw	1005080161
42	Threaded pin	1087050082
43	Tube for body	4427104300
44	Tension sleeve	1141040220
45	Axis	4427104500
46	Threaded pin	1087060101
48	Retaining handle, long	4427104800
49	Locking washer	1361000700
50	Tension spring	3452100800
51	Cheese head screw	1003060110
52	Type plate	3550205500
54	Shim ring	1311016054
500	Steel rocker, complete	4842714010



TITAN Strapping Systems, LP

306 West Plaza Drive, Suite B15 • Mooresville, NC 28117

Phone: (704) 663-2490 • Fax: (704) 663-2489

Email: rep@titanstrapping.com